

**MagicWatch WPS 900F / WPS 910 Application & Functionality: 010-2012 SW:V2- 29.0**

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
<b>Alfa Romeo</b>						
	Brera : 2006		YES	YES	CAN HIGH: N:6 PINK-BLACK CAN LOW: N:5 PINK-WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
	Guletta : 2010		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9.
	GT : 2004		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE (red retention), 40-pin marked G on front of fuse box to left of steering wheel. Position (H and L): No. 27 and No. 26.
	Mto : 2008		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9.
	147		YES	YES	CAN HIGH: PINK-BLACK CAN LOW: PINK-WHITE	Connector: BLUE (red retention), 40-pin marked G on front of fuse box to left of steering wheel. Position (H and L): No. 27 and No. 26.
	159 : 2006		YES	YES	CAN HIGH: PINK-BLACK CAN LOW: PINK-WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
<b>Aston Martin</b>						
	Vantage : 2006		YES	YES	CAN H = RED / BROWN CAN LO = RED / BLACK	The CAN wiring is located at the Body Diagnostic socket, drivers side, bottom of the dash panel. There are 2 diagnostic sockets marked 'Body' & 'OBD'.
	DB9 : 2006		YES	YES	CAN H = Pin 3 CAN LO = Pin 11	The CAN wiring is located at the OBD socket, drivers side, bottom of the dash panel.
<b>Audi</b>						
	A1 : 2010		YES	YES	CAN H = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	A3 : 2002		YES	YES	CAN HIGH: ORANGE-PURPLE CAN LOW: ORANGE-BROWN	Connector: 12-pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side. Position (H and L): No. 8 and No. 7.
	A3 : 2010		YES	YES	CAN H = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	A4 : 2002		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: GREY-VIOLET 32-pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (H and L): Nr. 13 and Nr. 12.
	A4 : 2005		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: GREY-VIOLET 32-pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (H and L): Nr. 13 and Nr. 12.
	A4 : 2007		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A5 : 2007		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A6 : 2002		YES	YES	CAN HIGH: ORANGE-PURPLE CAN LOW: ORANGE-BROWN	Remove the audio unit. The interface is installed to the CAN wiring at the audio connector.
	A6 : 2011	NEW	YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14, or Wire bundle to left of steering wheel behind lower plastic cover of dashboard.
	A7 : 2011		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14.
	A8 : 2003		YES	YES	CAN HIGH: ORANGE-PURPLE CAN LOW: ORANGE-BROWN	Remove the audio unit. The interface is installed to the CAN wiring at the audio connector.
	A8 : 2011		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14.
	Q3 : 2011		YES	YES	CAN H = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Q5 : 2008		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14.
	Q7 : 2006		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14.
	R8 : 2007		YES		CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: 12-pin BLACK connector G connected to black control unit fastened underneath dashboard, driver's side. Position (H and L): No. 8 and No. 7.
	S5 : 2007		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: LIGHT BROWN, 16-pin connected to electronic module underneath the dashboard, driver's side, at top near clutch pedal. Pos. (H and L): No. 15 and No. 14.
	S6 : 2002		YES		CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: GREY-VIOLET 32-pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (H and L): Nr. 13 and Nr. 12.
	TT : 2002		YES		CAN HIGH: ORANGE-PURPLE CAN LOW: ORANGE-BROWN	Remove the audio unit. The interface is installed to the CAN wiring at the audio connector.
	TT : 2007		YES		CAN H = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 6 and Nr. 7.
<b>BMW</b>						
	1 Series (E87) : 2005 (- 2011)		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: BLACK-GREY 51-pin connected to light electronic module behind the kick plate, driver's side. Position (H and L): Nr. 46 and Nr. 45.
	3 Series (E46) : 2002		YES	YES	CAN H: YELLOW-BLACK CAN LO: YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.
	3 Series (E90) : 2005		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plug. The CAN wiring can also be located at the audio unit Quadlock. The CAN bus wiring is a twisted pair of wires.
	5 Series (E60) : 2003		YES	YES	CAN H: BLACK CAN LO: YELLOW	Connector: BLACK 41-pin connected to white electronic module "CAS", fastened to the left of steering column. Position (H and L): Nr. 35 and Nr. 26.
	5 Series (F10) : 2010		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module (aluminum case), fastened to the left of the steering column.
	6 Series (E63) : 2004		YES	YES	CAN H: BLACK CAN LO: YELLOW	Connector: WHITE 76-pin connected to to the back electronic module "CAS", fastened to the left of steering column. Position (H and L): Nr. 14 and Nr. 32.
	X1 (E84) : 2009		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: BLACK-GREY 51-pin connected to light electronic module behind the kick plate, driver's side. Position (H and L): Nr. 46 and Nr. 45.
	X5 (E53) : 2000		YES	YES	CAN H: YELLOW-BLACK CAN LO: YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector: White 12 pole behind the gloves compartment passenger side.
	X5 (E70) : 2007		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: BLACK 41-pin connected to white electronic module "CAS", fastened to the left of steering column. Position (H and L): Nr. 35 and Nr. 26.
	X3 (E46) : 2003		YES	YES	CAN H: YELLOW-BLACK CAN LO: YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires. Or Connector: White 12 pole behind the gloves compartment passenger side. Position (H and L): No.5 and No.6
	X3 (F25) : 2011		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: LIGHT BLUE (black retention) connected to electronic module, fastened to the left of the steering column.
	X6 (E71) : 2008		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: GREEN	Connector: BLACK 41-pin connected to white electronic module "CAS", fastened to the left of steering column. Position (H and L): Nr. 35 and Nr. 26.
	Z4 (E46) : 2003		YES	YES	CAN H: YELLOW-BLACK CAN LO: YELLOW-BROWN	Connected behind to speedometer assembly, the Can-bus wiring is a twisted pair of wires.
<b>Cadillac</b>						
	Escalade : 2006		YES	YES	CAN H: BEIGE-BLACK PIN.6 CAN LO: BEIGE PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No.1 and G.N.D.)
<b>Chevrolet</b>						
	Camaro : 2009		YES	YES	CAN HIGH: PIN.1 CAN LOW: GND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D.
	Aveo : 2011		YES	YES	CAN H: BROWN-BLACK PIN.6 CAN LO: BROWN PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 Green and G.N.D.)
	Captiva : 2007 (- 2011)		YES	YES	CAN H: BROWN-BLACK PIN.6 CAN LO: BROWN PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
	Colorado : 2007		YES		CAN H: BROWN-BLACK PIN.6 CAN LO: BROWN PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
	Cruze : 2010		YES	YES	CAN HIGH: GREEN PIN.1 CAN LOW: GND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D.
	Escalade : 2006		YES	YES	CAN H: BROWN-BLACK PIN.6 CAN LO: BROWN PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
	HHR : 2006		YES		CAN HIGH: PIN.1 CAN LOW: GND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D.
	Malibu : 2008		YES	YES	CAN H: PIN.6 CAN LO: PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
	Orlando : 2010		YES	YES	CAN HIGH: GREEN PIN.1 CAN LOW: GND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D.
	Spark : 2010		YES		CAN H: BROWN-BLACK PIN.6 CAN LO: BROWN PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
	Volt : 2011		YES		CAN H: PIN.6 CAN LO: PIN.14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or ( No. 1 and G.N.D.)
<b>Chrysler</b>						
	300C		YES		CAN H = WHITE / ORANGE CAN LO = WHITE / RED	The CAN wiring is located at the radio wiring connector. Remove the dash facia panel (clipped) and unlock the radio for access.

## MagicWatch WPS 900F / WPS 910 Application &amp; Functionality: 010-2012 SW:V2- 29.0

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
<b>Citroen</b>						
	Berlingo : 2008		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14 or (No.10 and No.13 rear at the audio Quadrok)
	Citroen C2 :		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	C3 : 2002		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	C4 : 2005		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	C5 : 2005		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	C8 : 2003		YES	YES	CAN HI = WHITE CAN LO = PURPLE	The CAN wiring is located in a wiring loom - behind drivers side dash. The CAN bus wiring is a twisted pair of wires, coloured as below:
	C-Crosser : 2007		YES	YES	CAN HI = GREEN (behind speedometer) - ORANGE CAN LO = PINK (behind speedometer) - WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector: WHITE 20-PIN behind the radio CAN HIGH No.8 ORANGE and CAN LOW No.18 WHITE.
	Jumpy-Dispatch : 2007		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	DS3 : 2010		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	Nemo : 2008		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No.1 and No. 9 or (No. 6 and No. 14)
	Picasso : 2005		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
<b>Dacia</b>						
	Duster : 2010	NEW	YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No.14
	Lodgy : 2012	NEW	YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No.14
<b>Daihatsu</b>						
	Terios : 2011		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No.14
<b>Dodge</b>						
	Caliber : 2007		YES	YES	CAN HI = WHITE / ORANGE CAN LO = WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
	Caravan : 2009		YES		CAN HI = WHITE / ORANGE CAN LO = WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
	Challenger : 2011		YES	YES	CAN HI = GREEN CAN LO = WHITE	The CAN wiring is located at the LCD screen connector. Also located in the main loom behind the drivers side lower dash kick panel.
	Charger : 2009		YES	YES	CAN HI = WHITE / ORANGE CAN LO = WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
	Durango : 2009		YES		CAN HI = WHITE / ORANGE CAN LO = WHITE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
	RAM : 2009		YES	YES	CAN HI = WHITE / GREY CAN LO = WHITE / ORANGE	The wiring is located at the radio connector. Also located in the main loom behind the drivers side lower dash kick panel.
<b>Fiat</b>						
	Bravo : 2007		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
	Doblo : 2001		YES		CAN HIGH: GREY / BLACK CAN LOW: WHITE / GREEN	The CAN wiring is located at the radio wiring ISO connector. Position (H and L): No. 1 and No. 3.
	Doblo : 2011 >		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9. Or position No. 6 and No.14
	Ducato : 2002		YES	YES	CAN HIGH: PIN 6 CAN LOW: PIN 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14
	Ducato : 2007		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5 or in to the ISO radio connector.
	Ducato Euro 5: 2011		YES	YES	CAN HIGH: PIN 1 BLACK/ORANGE CAN LOW: PIN 9 WHITE/ORANGE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9. Or No. 6 and No.14
	Florino : 2008		YES	YES	CAN HIGH: PINK / BLACK CAN LOW: PINK / WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14. Or position No. 1 BLUE and No.9 WHITE
	Freemont : 2011		YES	YES	CAN HIGH: PIN 3 GREY CAN LOW: PIN 11 WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No.11
	Grande Punto : 2006		YES	YES	CAN HIGH: PIN 6 CAN LOW: PIN 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14. Or position No. 1 BLUE and No.9 WHITE
	Panda : 2005		YES	YES	CAN HIGH: PINK / BLACK CAN LOW: PINK / WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14. Or position No. 1 BLUE and No.9 WHITE
	Punto : 2003		YES	YES	CAN HIGH: PINK / BLACK CAN LOW: PINK / WHITE	Connected to connector Blue red clip at the front of the fuse box. Position (H and L): No. 27 and No. 26
	Scudo : 2007		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	Stilo : 2002		YES	YES	CAN HIGH: PINK / BLACK CAN LOW: PINK / WHITE	Connector: BLACK 32 pin on left underneath steering column on fuse box. Position (H and L): Nr. 28 and Nr. 10.
	500 : 2007		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9. Or No. 6 and No.14
<b>Ford</b>						
	F-150 : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14
	F-250 : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14
	F-350 : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14
	F-350 : 2010		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14
	Espace : 2008		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Fiesta : 2004		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14 or (No.9 and No.10 rear at the audio Quadrok)
	Fiesta : 2008 (- 2011)		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Focus C-Max : 2003		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Focus C-Max : 2011		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Focus S-Max : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14. Or position No. 3 and No.11 Without RPM
	Focus : 2005		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Focus : 2011		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Focus (USA) : 2005		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Fusion : 2004		YES		CAN HI = GREY / RED CAN LO = BLUE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Fusion (USA): 2010		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Galaxy : 2006		YES	YES	CAN HI = ORANGE / BLACK or ORANGE / GREEN CAN LO = ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
	Ka : 2008		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No.1 and No. 9. Or No. 6 and No.14
	Kuga : 2009		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
	Mondeo : 2002		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Mondeo : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Mustang : 2005		YES	YES	CAN HI = WHITE / RED CAN LO = PINK / RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, coloured as below:
	Transit : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14 or (No.9 and No.10 rear at the audio Quadrok)
	Transit Connect : 2007		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No.3 and No.11 or (No.9 and No.10 rear at the audio Quadrok)
<b>Honda</b>						
	Accord : 2003 (- 2010)		YES	YES	CAN HI = WHITE CAN LO = RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Civic : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Crossroad : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	CR-V : 2007		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	CR-Z : 2010		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.

## MagicWatch WPS 900F / WPS 910 Application &amp; Functionality: 010-2012 SW:V2- 29.0

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
	Element : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	FR-V : 2006		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Freed : 2008		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Insight : 2008		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Odyssey : 2004		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Stepwagon : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Hummer</b>						
	H2 : 2008		YES	YES	CAN HI = Pin 6 - BROWN/BLACK CAN LO = Pin 14 - BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Hyundai</b>						
	i-10 : 2009		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	i-20 : 2009		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	i-30 : 2008	Clutch from SWV 27.3	YES		CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - YELLOW	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	i-30 : 2012		YES		CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - YELLOW	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	i-40 : 2012		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - YELLOW	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	ix-35 : 2010		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Load : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	H1 : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Santa Fe : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Tucson : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Veloster : 2011		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Infinity</b>						
	FX45 : 2005		YES	YES	CAN HI = Pin 6 - BLUE CAN LO = Pin 14 - RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	FX35 : 2005		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Isuzu</b>						
	D-Max : 2006		YES		CAN HI = BLUE CAN LO = YELLOW/WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	D-Max : 2012	NEW	YES		CAN HI = BLUE CAN LO = YELLOW/WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Iveco</b>						
	Daily : 2006		YES	YES	CAN HI = PINK/BLACK CAN LO = PINK/WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
<b>Jaguar</b>						
	S - Type : 2001		YES		CAN HI = GREY/RED CAN LO = BLUE/RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	X - Type : 2001		YES	YES	CAN HI = GREY/RED CAN LO = BLUE/RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	X F : 2008		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	X F : 2011		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	XKR - XKB : 1996		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	XK-R : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	XJ6 - XJ8 : 2003		YES	YES	CAN HI = Pin 6 - YELLOW CAN LO = Pin 14 - GREEN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Jeep</b>						
	Cherokee (KJ) : 2001 (- 2007)		YES		CAN HI = WHITE / ORANGE CAN LO = WHITE / GREY	The CAN bus wiring is a twisted pair of wires, is located at the radio wiring connector. Remove the dash fascia panel (clipped) and unbolt the radio for access.
	Grand Cherokee (D)		YES		CAN HI = WHITE / ORANGE CAN LO = WHITE	The CAN bus wiring is a twisted pair of wires, is located at the radio wiring connector. Remove the dash fascia panel (clipped) and unbolt the radio for access.
	Compass : 2011		YES		CAN HI = WHITE / ORANGE CAN LO = WHITE / PURPLE	The CAN bus wiring is a twisted pair of wires, is located at the radio wiring connector. Remove the dash fascia panel (clipped) and unbolt the radio for access.
	Wrangler : 2007		YES	YES	CAN HI = WHITE / ORANGE CAN LO = WHITE	The CAN bus wiring is a twisted pair of wires, is located at the radio wiring connector. Remove the dash fascia panel (clipped) and unbolt the radio for access.
<b>Kia</b>						
	Carans : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Ceed : 2007		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Ceed : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Optima : 2011	NEW	YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Picanto : 2011		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Sorento : 2009		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Soul : 2008		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Sportage : 2010		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Venga : 2009		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Lamborghini</b>						
	Gallardo : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Lancia</b>						
	Delta : 2008		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
	Musa : 2004		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Thema : 2012		YES	YES	CAN HIGH: PIN.3 GREY CAN LOW: PIN.11 WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11
	Ypsilon : 2003		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
	Ypsilon : 2011		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Land Rover</b>						
	Defender : 2007		YES		CAN HI = BLUE / BLACK CAN LO = GREEN / BLACK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Defender : 2011	Only for diesel engine	YES	YES	CAN HI = Pin 6 Or Pin 3 CAN LO = Pin 14 Or Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Discovery 3 : 2005		YES	YES	CAN HI = Pin 6 Or Pin 3 CAN LO = Pin 14 Or Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Discovery 4 : 2010		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	Freelander : 2000		YES		CAN HI = YELLOW / BLACK CAN LO = YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Freelander 2 : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Range Rover : 2002		YES		CAN HI = Pin 6 - YELLOW / BLACK CAN LO = Pin 14 - YELLOW / BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14 Or Position (H and L): No. 3 WHITE/YELLOW and No. 11 YELLOW/BLUE
	RR Sport : 2005		YES	YES	CAN HI = Pin 6 - YELLOW / BLACK CAN LO = Pin 14 - YELLOW / BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Lexus</b>						
	is250 : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.

**MagicWatch WPS 900F / WPS 910 Application & Functionality: 010-2012 SW:V2- 29.0**

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
	rx 350 : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	rx 400H : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Maserati</b>						
	Gran Turismo 2007		YES	YES	CAN HIGH: N:6 PINK-BLACK CAN LOW: N:5 PINK-WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and Nr. 5.
<b>Mazda</b>						
	2 - 2003		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	3 - 2004		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	5 - 2005		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	6 - 2005		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	CX-5 : 2012		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	CX-7 : 2006		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	CX-9 : 2007		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Demio : 2005		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	MPV : 2004		YES		CAN HI = Pin 6 - BLUE / WHITE CAN LO = Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	MX-5 : 2006		YES		CAN HI = Pin 6 - BLUE / WHITE CAN LO = Pin 14 - GREEN / BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	RX-8 : 2004		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Mercedes</b>						
	A - Class 168 : 2000		YES	YES	CAN HI = GREEN/WHITE CAN LO = GREEN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	A - Class 169: 2004		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Connected in the door harness behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	B - Class T245 : 2005		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Connected in the door harness behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	B - Class W246 : 2011		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Connected in the door harness behind the kick plate, passenger's side or driver's side. The CAN bus wiring is a twisted pair of wires.
	C - Class W203 : 2000		YES	YES	CAN HI = GREEN/WHITE CAN LO = GREEN	Remove the lower drivers side under panel. Locate the ignition barrel loom or control unit loom. The CAN bus wiring is a twisted pair of wires.
	C - Class W204 : 2007	Reverse only with auto gearbox	YES	(AUTO)*	CAN HI = BROWN / RED CAN LO = BROWN	The wiring is located in the main loom behind the drivers side lower dash kick panel. The Reverse Gear output is only available on Automatic vehicles
	CL : 2007	Reverse only with auto gearbox	YES	(AUTO)*	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLK : 2002		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	CLS : 2007		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	CLS W218 : 2011	Reverse only with auto gearbox	YES	(AUTO)*	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	E - Class W211 : 2000		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	E - Class W212 : 2009	Reverse only with auto gearbox	YES	(AUTO)*	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	G - Class : 2009		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower passenger side under panel. The CAN-bus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	M - Class : 1999		YES	YES	CAN HI = WHITE CAN LO = GREEN	Remove the lower drivers side under panel. The CAN wires are located at the control module. The CAN bus wiring is a twisted pair of wires.
	M - Class : 2006		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Connected in the CAN-bus concentrator connector wires, behind the kick plate, passenger's side. The CAN bus wiring is a twisted pair of wires.
	R - Class : 2006		YES	(AUTO)*	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower passenger side under panel. The CAN-bus wires are located in concentrator connector black. The CAN bus wiring is a twisted pair of wires.
	S - Class : 2000		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side under panel. The CAN wires are located on the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	S - Class : 2006		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	SL - Class : 2001		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	SLK : 2004		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side under panel. The CAN wires are located at the black CAN-bus junction connector. The CAN bus wiring is a twisted pair of wires.
	Sprinter : 2000		YES		CAN HI = GREEN/WHITE CAN LO = GREEN	Remove the vehicle speedometer cover. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Sprinter : 2006		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	Vaneo : 2000		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Vito : 2004		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
	Viano : 2003		YES	YES	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower drivers side under panel. The CAN wires are located at near the kick panel. Also at the speedometer. The CAN bus wiring is a twisted pair of wires.
<b>Mini</b>						
	Mini : 2001		YES		CAN HI = YELLOW / BLACK CAN LO = YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Mini : 2007		YES	YES	CAN HI = ORANGE / GREEN CAN LO = GREEN	Connector: BLACK/GRAY 51 pin the connector is located on the lights control unit behind the driver side lower dash kick panel. Position (H and L): Nr. 46 and Nr. 45.
	Countriman: 2010		YES		CAN HI = Pin.26 ORANGE / GREEN CAN LO = Pin.13 GREEN	Connector: BLACK 52 pin the connector is located in the junction box on the right side passenger glove compartment. Position (H and L): Nr. 26 and Nr. 13.
<b>Mitsubishi</b>						
	ASX : 2010		YES	YES	CAN HI = BLACK CAN LO = WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Colt : 2005		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Lancer Evo 10 : 2008		YES	YES	CAN HI = GREEN CAN LO = PINK	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	L200 : 2012		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Grandis : 2004		YES	YES	CAN HI = Pin 6 - Pin 4 - RED / BLUE CAN LO = Pin 14 - Pin 3 - BLACK / BLUE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Outlander : 2007		YES	YES	CAN HI = GREEN (behind speedometer) - ORANGE CAN LO = PINK (behind speedometer) - WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector: WHITE 20-PIN behind the radio CAN HIGH No.8 ORANGE and CAN LOW No.18 WHITE.
<b>Nissan</b>						
	Almera : 2002		YES	YES	CAN HI = BLUE CAN LO = RED	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires, coloured as below.
	Almera : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Cube : All Models		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Elgrand : 2002		YES	YES	CAN HI = Pin 6 - Pin 4 - PINK CAN LO = Pin 14 - Pin 5 - BLUE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.

**MagicWatch WPS 900F / WPS 910 Application & Functionality: 010-2012 SW:V2- 29.0**

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
	Micra : 2003		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Murano : 2004 (- 2010)	Only for gasoline eng.	YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Juke : 2010		YES		CAN HI = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Navarra : 2006		YES	YES	CAN HI = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Note : 2005		YES	YES	CAN HI = BLUE CAN LO = YELLOW	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	NV : 2010		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Pathfinder : 2006		YES	YES	CAN HI = BLUE CAN LO = PINK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Piso : 2009		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Primera : 2002		YES	YES	CAN HI = BLUE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Qashqai : 2008	Only for diesel engine	YES	(MAN)*	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Rouge : 2008		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Sentra : 2008		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Skyline : 2003		YES	YES	CAN HI = BLUE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	X-Trail : All Models		YES		CAN HI = WHITE CAN LO = RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	350Z - 370Z : 2003		YES		CAN HI = 6 CAN LO = 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Opel</b>						
	Agila : 2009		YES	YES	CAN HI = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Ampera : 2011		YES		CAN HI = BROWN / BLACK CAN LO = BROWN	The CAN wiring is located at the OBD socket, under the drivers side dash. Position (H and L): No. 6 and No. 14.
	Antara : 2007		YES	YES	CAN HI = BROWN / BLACK CAN LO = BROWN	The CAN wiring is located at the OBD socket, under the drivers side dash. Position (H and L): No. 6 and No. 14.
	Astra H : 2004		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connector: GRAY-BLACK 102-PIN connected behind the kick plate, driver's side. Position (H and L): No. 50 Or Connected to connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	Astra J : 2010		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connector: BLUE 27-PIN connected underneath car radio. Position (H and L): No. 22 Or Connected to connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	Corsa - Combo : 2001		YES	YES	CAN HI = GREEN CAN LO = WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Combo : 2012		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9. Or position No. 6 and No. 14
	Corsa : 2006		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Meriva : 2004		YES	YES	CAN HI = GREEN CAN LO = WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Meriva : 2010		YES	YES	CAN HI = GREEN CAN LO = WHITE	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): No. 6 and No. 14.
	Insignia : 2009		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D. Or Position (H and L): No. 6 and No. 14.
	Movano : 2003		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Movano : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD inside the glove box. Position (H and L): No. 6 and No. 14.
	Signum : 2003		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connector: GRAY-BLACK 102-PIN connected behind the kick plate, driver's side. Position (H and L): No. 97. Or connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	Tigra : 2005		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	Vectra : 2004		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	Vivaro : 2003		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Zafira : 2005		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connector: GRAY-BLACK 102-PIN connected behind the kick plate, driver's side. Position (H and L): No. 50 Or Connected to connector OBD underneath car radio. Position (H and L): No. 6 and No. 14.
	GT : 2007		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Peugeot</b>						
	207 : 2006		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	208 : 2012		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	307 : 2001		YES	YES	CAN HI = GREEN CAN LO = GREY	Remove the lower passenger side under panel. The CAN wires are located at the BSI module. The CAN bus wiring is a twisted pair of wires on a black multi-plug.
	307 : 2005		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	308 : 2008		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	407 : 2001		YES	YES	CAN HI = WHITE CAN LO = GREY	Remove the lower passenger side under panel. The CAN wires are located at the BSI module. The CAN bus wiring is a twisted pair of wires on a black multi-plug.
	807 : 2003		YES	YES	CAN HI = Pin 6 - WHITE CAN LO = Pin 14 - PURPLE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	3008 : 2009		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed and reverse signal)
	4007 : 2007		YES	YES	CAN HI = GREEN (behind speedometer) - ORANGE CAN LO = PINK (behind speedometer) - WHITE	Remove the vehicle speedometer assembly. The CAN bus wiring is a twisted pair of wires. Or Radio Connector: WHITE 20-PIN behind the radio CAN HIGH No.8 ORANGE and CAN LOW No.18 WHITE.
	5008 : 2010		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No. 10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
	Boxer : 2007		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connector: BLUE 36 pin (green part) at rear of fuse box. Position (H and L): Nr. 6 and No. 5 or in to the ISO radio connector.
	Bipper : 2008		YES	YES	CAN HIGH: BLUE CAN LOW: WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and No. 9 or ( No. 6 and No. 14)
	Expert : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or (No.10 and No.13 rear at the audio Quadok)
	Partner : 2003		YES	YES	CAN HI = GREEN CAN LO = BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No.6 and No.14. or (No.10 and No.13 rear at the audio Quadok)
	Partner : 2008		YES	YES	CAN HI = Pin 10 CAN LO = Pin 13	Connecting to position No.10 and No.13, rear at the audio quadlock connector ( Position H and L: No.6 and No.14 on OBDII connector only for speed signal)
<b>Porsche</b>						
	Boxster : 2000		YES	YES	CAN HI = WHITE / BLUE CAN LO = WHITE / GREY	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires at the GREEN plug.
	Boxster : 2004		YES		CAN HI = YELLOW CAN LO = BLACK	Remove the drivers side kick trim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.
	911 : 2004		YES	YES	CAN HI = YELLOW CAN LO = BLACK	Remove the drivers side kick trim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.
	Cayenne : 2003		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Cayman : 2005		YES	YES	CAN HI = YELLOW CAN LO = BLACK	Remove the drivers side kick trim which houses the fuse box. The CAN wiring is located in the main loom to the side. The CAN bus wiring is a twisted pair of wires.
<b>Renault</b>						
	Clio : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Espace : 2003		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Kangoo : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Koleos : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Laguna (II) : 2003		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14.



**MagicWatch WPS 900F / WPS 910 Application & Functionality: 010-2012 SW:V2- 29.0**

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
	Laguna (III) : 2008		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, under the cup holder in the below the centre arm rest. Position (H and L): No. 6 and No. 14.
	Master : 2003		YES		CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, behind the drivers side lower dash panel. Position (H and L): No. 6 and No. 14.
	Master : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, inside the glove compartment. Position (H and L): No. 6 and No. 14.
	Megane : 2001		YES	YES	CAN HI = PINK CAN LO = BROWN / WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. Position (H and L): No. 6 and No. 14.
	Megane : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, under the radio behind a plastic panel. Position (H and L): No. 6 and No. 14.
	Modus : 2003		YES	YES	CAN HI = ORANGE CAN LO = BROWN	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Scenic : 2004		YES	YES	CAN HI = BROWN / WHITE CAN LO = ORANGE / WHITE	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Scenic : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Traffic : 2003		YES		CAN HI = PURPLE / RED CAN LO = WHITE / RED	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Vel Satis : 2002		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, under a rubber cover below the ashtray. Position (H and L): No. 6 and No. 14.
	Wind : 2010		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, inside the glove box. Position (H and L): No. 6 and No. 14.
<b>Rover</b>						
	75 / MG ZT : 2000		YES		CAN HI = YELLOW / BLACK CAN LO = YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	75 (V8) : 2000		YES		CAN HI = YELLOW / BLACK CAN LO = YELLOW / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
<b>Saab</b>						
	93 : 2006		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D. Or Position (H and L): No. 6 and No. 14.
	95 : 2006		YES	YES	CAN HI = GREEN CAN LO = WHITE	Remove the vehicle Glove Box. The CAN wires are located at the Left Hand Main Loom. Position (H and L): No. 6 and No. 14.
	95 : 2010		YES	YES	CAN HI = GREEN - OBD Pin 1 CAN LO = BLACK - OBD Pin 4	The CAN wires are available at the OBD connector under the drivers dash.
	97 : 2006		YES	YES	CAN HI = GREEN CAN LO = CONNECT TO GROUND	Connected to connector OBD on left underneath steering column. Position (H and L): No. 1 and G.N.D. Or Position (H and L): No. 6 and No. 14.
<b>Scania</b>						
	R570 : 2004	Pay attention to the supply	YES	YES	CAN HI = YELLOW CAN LO = WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
	R480 : 2004	Pay attention to the supply	YES	YES	CAN HI = YELLOW CAN LO = WHITE	The CAN wiring can be found in the main loom under the passenger fuse box and also at the speedometer assembly. The CAN bus wiring is a twisted pair of wires.
<b>Seat</b>						
	Alhambra : 2000		YES	YES	CAN HI = ORANGE / BLACK or ORANGE / GREEN CAN LO = ORANGE / BROWN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
	Altea : 2004		YES	YES	CAN HI = YELLOW CAN LO = BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Altea : 2008		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Altea : 2011		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Exeo : 2009		YES	YES	CAN HIGH: ORANGE-GREEN CAN LOW: ORANGE-BROWN	Connector: GREY-VIOLET 32-pin connector connected to Black control unit fastened underneath dashboard, driver's side. Position (H and L): Nr. 13 and Nr. 12.
	Ibiza : 2003		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 18 pin (marked XS2) the connector is located the lower drivers side under panel Position (H and L): Nr. 12 and Nr. 9.
	Ibiza : 2010		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: WHITE controller box, the connector is located the lower drivers side under panel
	Leon : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Leon : 2011		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
<b>Skoda</b>						
	Fabia : 2002		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 18 pin (marked XS2) the connector is located the lower drivers side under panel Position (H and L): Nr. 12 and Nr. 9.
	Fabia : 2010		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: WHITE controller box, the connector is located the lower drivers side under panel
	Octavia : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Octavia II : 2009		YES	YES	CAN HI = ORANGE / GREEN or ORANGE / PURPLE CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Roomster : 2009		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 18 pin (marked XS2) the connector is located the lower drivers side under panel Position (H and L): Nr. 12 and Nr. 9.
	Superb : 2008		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 18 pin (marked XS2) the connector is located the lower drivers side under panel Position (H and L): Nr. 12 and Nr. 9.
	Yeti : 2009		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
<b>Smart</b>						
	FourTwo : 2007		YES	YES	CAN HI = GREEN / WHITE CAN LO = GREEN	Remove the vehicle audio unit. The CAN wires are located in the loom running, vertical towards the heater panel at the top of the dash. The CAN bus wiring is a twisted pair of wires, coloured as below:
<b>Subaru</b>						
	Forester : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Impreza : 2008		YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Legacy : 2009	NEW	YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Outback : 2009	NEW	YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	XV : 2012	NEW	YES		CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Suzuki</b>						
	Alto : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Grand Vitara : 2006		YES	YES	CAN HI = Pin 6 - RED CAN LO = Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Splash : 2009		YES	YES	CAN HI = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Swift : 2005		YES	YES	CAN HI = RED/BLACK CAN LO = WHITE/BLACK	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	SX4 : 2006		YES	YES	CAN HI = Pin 6 - RED CAN LO = Pin 14 - WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Toyota</b>						
	Avenis : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Auris : 2007		YES	YES	CAN HI = GREEN CAN LO = WHITE	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	BB : 2007		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, near the centre console under drivers side dash. Position (H and L): No. 6 and No. 14.
	Estima : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): No. 6 and No. 14.
	Land Cruiser : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Prius : 2005		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Prius : 2009		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	RAV4 : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.

## MagicWatch WPS 900F / WPS 910 Application &amp; Functionality: 010-2012 SW:V2- 29.0

Manufacturer	Modell	Note	Speed	Reverse	Wire connections	Position
	Verso S : 2011		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 8 and No. 14.
	Yaris : 2006		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
	Yaris : 2011		YES	YES	CAN HI = Pin 6 CAN LO = Pin 14	Connected to connector OBD on left underneath steering column. Position (H and L): No. 6 and No. 14.
<b>Volkswagen</b>						
	Amarok : 2011		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Remove the lower drivers side under panel. The CAN wires are a twisted pair located in the main loom. WHITE connector 73 pins near the steering column. The CAN may also be available at the audio Quadlock connector.
	Beetle : 1999		YES	YES	CAN HI = ORANGE / BLACK CAN LO = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Beetle : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Caddy : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Caddy : 2010		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Caravelle : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 6 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 6 and Nr. 6.
	Crafter : 2008		YES	AUTO	CAN HI = BROWN / RED CAN LO = BROWN	Remove the lower driver side panel. The CAN wires are located in concentrator connector wires. The CAN bus wiring is a twisted pair of wires.
	Eos : 2006		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf V : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf VI : 2009		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Golf Plus : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Golf Plus : 2009		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Passat : 2002		YES	YES	CAN HI = ORANGE / BLACK CAN LO = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Passat : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Passat : 2011		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 52 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 15 and Nr. 16.
	Polo : 2005		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 18 pin (marked XS2) the connector is located the lower drivers side under panel Position (H and L): Nr. 12 and Nr. 9.
	Polo : 2010		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: WHITE controller box, the connector is located the lower drivers side under panel
	Routan : 2009		YES	YES	CAN HI = WHITE / GREY CAN LO = WHITE / ORANGE	The CAN bus wiring is a twisted pair of wires, is located at the radio wiring connector. Remove the dash fascia panel (clipped) and unbolt the radio for access.
	Scirocco : 2009		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Sharan : 2010		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	The CAN wires are located in the steering column loom. The CAN wiring is a twisted pair.
	Sharan : 2002		YES	YES	CAN HI = ORANGE / BLACK or ORANGE / BROWN CAN LO = ORANGE / GREEN or ORANGE / BROWN	The CAN wires are located at the GREEN connector located at the rear of the speedometer. Remove the steering column housing. There are 2 x Torx screws securing the speedometer. The CAN wiring is a twisted pair.
	Tiguan : 2007 (-2009)		YES	YES	CAN HI = ORANGE / PURPLE CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Touareg : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Remove the vehicle speedometer assembly. The CAN wires are located at the connection plugs. The CAN bus wiring is a twisted pair of wires.
	Touareg : 2011		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Remove the lower drivers side under panel. The CAN wires are a twisted pair located in the main loom "C" BROWN connector 16 pins near the steering column.
	Touran : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BLACK 12 pin (marked G) the connector is located the lower drivers side under panel Position (H and L): Nr. 8 and Nr. 7.
	Transporter : 2004		YES	YES	CAN HI = ORANGE / GREEN CAN LO = ORANGE / BROWN	Connector: BROWN 6 pin the connector is located the lower drivers side under panel Position (H and L): Nr. 6 and Nr. 6.
<b>Volvo</b>						
	C30 : 2007		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	C70 : 2001		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	S40 : 2005		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	S60 : 2001		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	S60 : 2010		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	V50 : 2005		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	V70 : 2000		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	V70 : 2011		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	The CAN wiring is located at the OBD socket, near the centre console under the gearchange lever Position (H and L): No. 3 and No. 11.
	XC60 : 2010		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	XC70 : 2000		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	XC70 : 2011		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.
	XC90 : 2003		YES	YES	CAN HI = Pin 3 CAN LO = Pin 11	Connected to connector OBD on left underneath steering column. Position (H and L): No. 3 and No. 11.

**Note:****Metal bumper:**For metal bumper you must use the special holder **9101500015 (4 pieces)!****Column IGNITION:**

For the vehicle applications shown with a ( YES ) in the Ignition column:

The system activates when the ignition is turned on and will remain live for 30 minutes if the vehicle ignition is turned off and the key is left in the ignition.

The ignition is turned off immediately when the key is taken off from the ignition.

**Column REVERSE:**

The meaning of (MAN) or (AUTO) in the reverse column is: the rear gear signal is available only on Manual gear vehicles or only in automatic gear box vehicles.

**Column CLUTCH:**

The meaning of (NO) in the Clutch column is: the clutch signal is available only on vehicles equipped with OEM cruise control